



VACUUMS

Parts for PF16BP



ref#	order	description
1	TB2	screw 4x16
2	TB618	washer, plain steel m4
3	TB27	wand locker
5	TB631	washer plain m8 x 30
6	TB632	screw back-vac m8 x 60
7	TB633	screw back-vac m8 x 50
8	TB640	nut m8 complete nylon
9	TB630	spacer 8.2 x r18xh30
11	TB628	connection bracket powr-pak
13	TB84	thumb screw 5x18
14	TB634	carry belt complete back vac
15	TB625	mudwing repair washer m5 x 20
19	TB638	hexagon screw m8 x 60
25	TB637	cable restrain
26	TB645	switch 10 amp



ref#	order	description
1	TB602	telescope wand 32 mm
6	TB607	hose cuff 35 mm pa special
7	TB608	30 degree bend 32 mm (plast.)
8	TB609	hose black 35 2,2 w/click ring
9	TB25	crevice tool
11	TB19	hose cuff black
14	TB18	hose clip with lip black
16	TB37	dust filter holder
17	TB38	dust filter
18	261PB	enviro-clean 10pk paper bag
19	TB601	hose end
20	TB17K	hose assembly

* call for pricing and availability