

Powr-Flite®

PARTS LIST

AUTOMATIC SCRUBBER


CAS16



**WARNING: OPERATOR MUST READ AND UNDERSTAND THIS MANUAL
COMPLETELY BEFORE OPERATING THIS EQUIPMENT.**

Automatic Scrubber Parts CAS16

FRAME ASSEMBLY




FRAME ASSEMBLY

No.	Part No.	Qty	Description
18	03-7978-1000	0.14	Soft Neoprene Sponge Strip
19	03-7979-0000	1	Motor Sealing Pad
20	CAS63	1	Vacuum Motor
22	SC347	2	Screw
29	02-4279-0000	1	Plasklip
30	CAS57	1	Handle Support
32	00-0800-0721	7	Nylock Nut
33	00-0800-0551	10	Washer
82	02-0254-0000	2	Starlock Washer
83	SC339	2	Wheel 8"
84	CAS49	2	Washer
126	CAS56	1	Axle
127	CAS111	1	Chassis
134	04-3409-0000	1	Bridge Rectifier 25A
135	CAS24	1	Self Tapper
136			Double-Sided Tape
137	X9282	1	EMI Filter 6A
138	PD8	1	Strain Relief
139	SC56	1	Strain Relief Nut
140	CAS101	1	Strengthening Bar
141	CAS81	2	Screw M4 x 10
142	CAS99	1	Outlet Filter
143	CAS98	1	Outlet Filter Cover
144	FD66	4	Screw

Automatic Scrubber Parts CAS16

BRUSH HEAD





BRUSH HEAD

No.	Part No.	Qty	Description
20	CAS75	1	Side Brush Assembly
48	CAS70	1	Bearing Plate Assembly
49	CAS88	1	Bearing 6003-2RS
52	CAS117	1	Sprocket Housing
53	CAS90	2	Screw M6 x 25
54	00-0600-0721	2	Nut
55	00-0800-0551	3	Washer
56	00-0800-0721	3	Nut
58	CAS118	1	Motor Pulley
59	CAS62	1	Motor
60	04-3940-0000	1	Circuit Breaker 120V 2.5A
62	00-0606-0171	1	Screw M6 x 6
64	CAS124	3	Screw M5 x 20
66	02-3245-0000	1	Circlip
67	CAS69	1	Motor Plate w/Bearing, Sprocket, and Housing (68, 70, 71)
68	CAS88	1	Bearing 6003-2RS
70	CAS93	1	Brush Sprocket
71	CAS117	1	Sprocket Housing
73	CAS83	2	Bearing 626-2RS
74	CAS87	1	Idler Pulley
76	CAS103	1	Washer
78	CAS90	2	Screw M6 x 25
79	00-0800-0551	2	Washer
80	00-0800-0721	2	Nylock Nut
86	CAS59	1	Belt
110	CAS54	1	Spray Bar
111	04-0286-0000	2	Cable Clamp
145	CAS115	1	Belt Cover
146	CAS102	3	Screw M5 x 25
147	CAS58G	1	Cylindrical Brush, Blue
	CAS58HB	1	Cylindrical Brush, Blue
	CAS58HL	1	Cylindrical Brush, Black
	CAS58SB	1	Cylindrical Brush, Blue
149	CAS71	1	Brush Shaft

Automatic Scrubber Parts CAS16

SOLUTION TANK




SOLUTION TANK

No.	Part No.	Qty	Description
1	CAS107	1	Solution Tank
3	SC303	1	Bulkhead Coupling
5	SC333	1	Filter
6	03-6041-0000	13"	Hose
36	SC304	1	Male Coupling Connector (Metal)
37	SC310	1	1/4" Elbow and Hosetail
38	CAS123	24"	Hose (Blue Coplexel)
39	SC144	2	Hose Clip
40	SC345	1	Hose Clamp
43	CAS64	1	Pump
44	CAS65	1	Pump Thermal Overload
45	FD66	4	Screw

Automatic Scrubber Parts CAS16

RECOVERY TANK




RECOVERY TANK

No.	Part No.	Qty	Description
4	CAS67	1	Dome Assembly
5	CAS105	1	Recovery Tank
6	CAS78	1	Recovery Tank Inlet Cover
7	CAS79	2	Recovery Tank Handle Pin
9	CAS77	1	Recovery Tank Inlet Cover Seal
10	00-0516-0013	2	Screw M5 x 16
24	CAS120	1	Hose Cuff
26	02-4369-0000	1	Hose Clamp
27	CAS119	1	Vacuum Hose
128	SC312	1	Squeegee Hose

Automatic Scrubber Parts CAS16

HANDLE ASSEMBLY









HANDLE ASSEMBLY

No.	Part No.	Qty	Description
1	02-3151-0000	1	P-Clip
2	B352-6900	1	Cable Strain Relief Bracket
3	CAS22	1	Gear Dog Spring
6	02-4492-0000	2	Splash proof Cover
7	03-5403-0000	1	Cable Winder
8	03-5410-0000	1	Cable Winder Spring
9	03-6086-0067	1	Handle Front
10	03-6087-0067	1	Handle Back
11	03-6089-0067	1	Gear Lever
12	03-6090-0067	2	Trigger Lever
13	CAS25	2	Rubber Molding
14	03-6092-0067	2	Handle Interlock
15	CAS34	1	Cord Retainer
16	CAS35	1	Handle Adjustment Gear
17	CAS36	1	Handle Adjusting Gear Dog
18	03-6693-0067	1	Socket Blanking Plate
19	CAS110	1	Knuckle
20	03-7917-0067	1	Trigger Blanking Plate
21	CAS38	1	Adjusting Rod
22	03-7927-0000	1	Oval Handle Tube
24	03-7936-0000	1	Operating Label
26	12-109	1	Cable Clamp
28	CAS40	1	Switch
30	CAS41	1	Input Socket
32	CAS43	2	Miniature Rocker Switch
34	00-0500-0511	1	Washer
37	00-0500-0701	5	Washer
41	00-0800-0501	2	Washer
42	00-0816-0111	2	Screw M8 x 16
43	CAS23	11	Screw
44	CAS24	2	Screw
45	13-922	2	Screw M4.5 x 13
46	02-3523-0000	1	Shoulder Bolt M6 x 8 x 40L
48	CAS39	1	Cord Inlet Box
Not Shown	04-0221-0000	1	Black Cable Tie
Not Shown	04-3246-0000	1	Power Cord
Not Shown	04-3733-0000	1	Handle Cord

Automatic Scrubber Parts CAS16


SQUEEGEE ASSEMBLY



SQUEEGEE ASSEMBLY

No.	Part No.	Qty	Description
88	03-7302-0000	2	Spring
90	CAS72	1	Vacuum Shoe Runner Assembly
96	CAS74	1	Wheel and Bearing
97	CAS82	1	Wheel
98	CAS83	2	Bearing
100	00-0600-0723	1	Nylock Nut
101	00-0640-0121	1	Bolt M6 x 40
103	CAS76	1	Front Squeegee Assembly
104	02-4543-0000	2	Pin
105	CAS84	2	Squeegee Blade
106	CAS122	2	Squeegee Roller
113	CAS108	1	Vacuum Shoe Assembly
116	03-7878-0067	1	Vacuum Shoe Base
117	CAS23	4	Self-Tapping Screw
119	CAS68	1	Rear Squeegee Assembly
121	CAS84	2	Squeegee Blades
152	SC347	4	Screw

WIRING DIAGRAM



For warranty information go to www.Powr-Flite.com

Powr-Flite®

A Tacony Company
3101 Wichita Court • Fort Worth, TX 76140-1755
800-880-2913 • Fax: 817-551-0719