

Powr-Flite[®]

PARTS LIST


Self-Contained Carpet Extractor Model PFX3S



**WARNING: OPERATOR MUST READ AND UNDERSTAND THIS MANUAL
COMPLETELY BEFORE OPERATING THIS EQUIPMENT.**

SCHEMATICS - PARTS LISTS

PFX3S MAIN ASSEMBLY



SCHEMATICS - PARTS LISTS


No	Part No.	Qty	Description
1	SC132	1	Set Screw M6 x 6
2	00-0500-0501	1	Washer
3	00-0500-0511	2	Spring Washer
4	00-0500-0521	1	Internal Toothed Washer
5	00-0500-0701	1	Nut
6	00-0510-0011	1	ScREW M5 x 10
7	00-0510-0031	1	Screw M5 x 10
8	CAS124	1	Screw M5 x 20
9	CAS102	1	Screw M5 x 25
10	SC137	4	Washer
11	SC136	4	Screw M6 x 12
12	00-0840-0123	2	Bolt M8 x 40
13	02-0254-0000	2	Starlock Washer
14	SC339	2	Wheel Complete (with Cap)
15	SC340	2	Wheel Cap
16	90-0010-0000	1	Cable Restraint
17	02-3381-0500	6	'O' Clip
18	02-3417-0000	4	Nylon Washer
19	SC231	1	1/8In Male Barb Connector
20	SC303	1	Female Bulkhead Coupling
21	SC305	1	Male Coupling Connector
22	SC308	1	Brush Motor Pulley
23	SC309	1	Brush Drive Belt
24	SC311	2	Handle Lock Knob
25	00-0512-0033	11	Screw M50 x 12
26	FD66	2	Screw M50 x 16
27	SC347	4	Screw M60 x 18
28	SC312	1	Pick Up Hose
29	02-3478-0000	2	Pump Out Hose Attachment Clamp
30	02-3708-0000	1	Strain Relief P Clip
31	02-4622-0000	1	Nut Wire Connector
32	03-5736-0000	2	Spacer
33	03-5987-0500	1	Rear Electrical Panel
34	03-5991-0000	2	Axle Retaining Plate
35	SC341	1	Bracket
36	03-6000-0500	1	Axle
37	03-6001-0000	1	Bracket
38	SC131	1	Gasket
39	SC154	1	Solution Tank
40	SC214	1	Bracket

SCHEMATICS - PARTS LISTS

No	Part No.	Qty	Description
41	03-6041-0000	1	Hose
42	03-6043-0000	1	Hose
43	03-6044-0000	1	Hose
46	SC333	1	Solution Tank Filter
47	03-8323-0000	1	1/4" Metal Elbow
48	SC325	1	Brush Motor
49	SC327	3	Switch/Splash Cover
50	04-3212-0000	1	Cable Gland
51	04-3221-0000	1	Suppressor
52	SC117	1	Terminal Block
53	FJ5082	1	Solenoid Pump w/ Rubber Mounts
54	04-3396-0000	1	Thermal Overload
55	CAS61	1	1.5 Amp Cutout
56	04-3409-0000	1	25 Amp Bridge Rectifier
57	05-3417-0039	1	Pick Up Assembly
58	05-3418-0000	1	Vac Motor Cover Assembly
59	05-3419-0000	1	Handle Assy
60	SC321	1	Recovery Tank
61	05-3423-0000	1	Complete Brush Assy
62	05-3427-0000	1	Drain Hose Assembly
63	04-3256-0000	1	Vacuum Motor
64	05-3728-0000	1	Bottom Cover Kit
Not Shown	M1369AS	1	Main Cable 14/3 SJTW Yellow 50 Feet

SCHEMATICS - PARTS LISTS


PFX3S HANDLE ASSEMBLY



No.	Part No.	Qty	Description
1	02-3457-0000	2	Tube End Cap
2	SC336	1	Handle Grip
3	02-3464-0000	3	Screw
4	SC116	2	Insert
5	02-4576-0000	3	Pipeclip
6	SC320	1	Handle Tube
7	03-6011-0000	1	Spray Jet Label
8	SC324	1	Handle Switch
9	05-3420-0000	1	Handle Switch Assembly

SCHEMATICS - PARTS LISTS


PFX3S RECOVERY TANK



No.	Part No.	Qty	Description
1	00-0500-0553	1	Washer
2	SC225	1	Dome
3	00-0512-0013	2	Screw M5 x 12
4	00-0516-0013	1	Screw M5 x 16
5	02-3525-0000	1	Chain
6	02-3527-0000	1	Spacer
7	02-3778-0000	1	O-Ring
8	SC317	1	Vacuum Lid, Gasket, and Chain
9	03-8301-0000	1	Filter
10	03-8304-0056	1	Recovery Tank
11	SC323	1	Vacuum Lid Gasket
12	SC317	1	Vacuum Lid, Gasket, and Chain
13	SC317	1	Vacuum Lid, Gasket, and Chain
14	SC317	1	Vacuum Lid, Gasket, and Chain

SCHEMATICS - PARTS LISTS


PFX3S BOTTOM HOUSING



No.	Part No.	Qty	Description
1	SC307	1	Spray Nozzle Retaining Nut
2	00-0512-0033	7	Screw M5 x 12
3	SC347	3	Screw M60 x 18
4	SC31	1	Spray Nozzle
5	03-6010-0000	2	Gasket
6	SC159	1	Brush Housing
7	03-6653-0000	1	Seal
8	SC318	1	Bottom Housing
9	03-8300-0000	1	Exhaust Port

SCHEMATICS - PARTS LISTS


PFX3S VACUUM MOTOR



No.	Part No.	Qty	Description
1	03-6692-0000	1	Vacuum Motor Inner Seal
2	04-3256-0000	1	Vacuum Motor
3	SC130	1	Vacuum Motor Rubber Seal

SCHEMATICS - PARTS LISTS

PFX3S WIRING DIAGRAM



WARNING NOTE:
ELECTRICAL MAINTENANCE
SHOULD ONLY BE
CARRIED OUT BY A
QUALIFIED ELECTRICIAN

For warranty information go to www.Powr-Flite.com

Powr-Flite®

A Tacony Company

3101 Wichita Court • Fort Worth, TX 76140-1755
1-800-880-2913 • Fax: 1-817-551-0719